




# GM Headlight Switch Connections


## Details for Front Parking Lights that stay On with Headlights

(\*\* This diagram applies to Coupe-23B Kits only \*\*)

© 2015 - 2016



### TERMINAL IDENTIFICATION



**Note:** If you want the front parking lights to remain ON with headlights, connect the front parking lights to the Tail Light Switch output terminal (same as rear tail lights). Connections will be different if you want the Front Parking Lights to turn Off when headlights are On, see separate diagram.