






Power Center Connections for Headlight Switch


Details of typical GM headlight switch with dome light switch

© 2018

(This diagram applies to Coach-1B Kits only)



TERMINAL IDENTIFICATION



NOTE: The Headlight Switch does not carry any high currents, it simply triggers the Parking Lamp and Headlight relays on the Power Center.