




Power Center Connections for Headlight Toggle Switch

Front Parking Lights turn Off when Headlights are On

(This diagram applies to Coupe-23A Kits only)

© 2017



COUPE-23A POWER CENTER